

5.2.2 Unable to Adjust Set point Setting to Obtain Trip

An improper air gap exists between hold down (lower) magnet and armature.
*Return the **Vibraswitch**® to the factory for repair.*

5.2.3 Switch Does Not Actuate

Defective Switch – verify by manually moving the Armature to the latched (tripped) position and listen for an audible click of the switch. Verify contact change-of-state by performing a continuity check.

If the switch does not pass either of the tests above, return the Vibraswitch® to the factory for repair.

Robertshaw

Schneider Electric Systems USA, Inc.

1602 Mustang Drive

Maryville, TN 37801

Telephone 865-981-3100

Fax 865-981-3168

Robertshaw Industrial Products by Schneider Electric